VENICCI HOME

Saluzzzo


Dresser





Assembly instruction

DO NOT DRAG 2 MAN LIFT










2/27

BEFOR ASSEMBLY


MAIN COMPONENTS

- -unpack all the parts and identify them against the fitting and components list.
- -do not discard any packaging until you have checked that you have all parts as shown below.
- -you may find the construction of your dresser easier if you have the help of another person.
- -crosshead screwdriver (not provided).



ARTIKELNUMMER ITEM NUMER ARTIKELNUMMER	вох	4021776	AANTAL QUANTITY ANZAHL	AFTMETINGEN [mm] DIMENSIONS [mm] ABMESSUNGEN [mm]		
1	1/2	2221519	1	825	500	22
2	1/2	2221520	1	791	449	16
3	2/2	2221531	1	825	80	16
4	1/2	2221521	1	648	479	16
5	1/2	2221522	1	648	479	16
6	2/2	2219800	1	803	514	3
7	2/2	2221523	1	791	150	16
8	1/2	2221528	3	751	106	16
9	1/2	2221526	3	400	120	16
10	1/2	2221527	3	400	120	16
11	1/2	2221529	3	764	405	3
12	2/2	2221525	3	819	179	16
13	2/2	2221532	1	825	80	16
14	2/2	2221533	2	500	56	16
15	2/2	2221531	1	825	80	16
16	1/2	1129816	4	180	58	33

EN. In case of complain please advise the spare part number.








x 2








x 2





4













































ATTENTION! Furniture shall be fixed to the wall to prevent it from falling over during the use. Fixing the furniture to the wall shall be carried out in accordance to instruction attached to the fitting




25





Appropriate tittings shall be chosen for slat assembly depending on wall kind. If you are not sure about the wall kind please consult it with an expert.




27 x 6 x 6 x 12







































Safety

Warning: Do not leave your child unattended.

Always use the wall attachment strap provided.

All assembly fixings should always be tightened properly. Care should be taken that no screws are loose because a child could trap parts of their body, or clothing (e.g. strings, necklaces, ribbons, dummies, etc.) which could pose a risk of strangulation.

Be aware of the risks of open fires and other such sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the dresser.

Suitable for use with a changing mat of max size **18x50** cm.

The changing area is suitable for use up to 12 months old or 11kg in weight.

Do not use the dresser if any of the parts are broken, torn or missing.

Any additional or replacement parts can only be obtained from the manufacturer or the distributor.

ensure there are no small parts fittings are left after assembly as these can be a chocking hazard.

This product conforms to: EN 12221-1:2008+A1:2013

Maintenance

Take care when handling or moving the furniture. Careless handling may cause damage.

Regularly check that all fixings are tightened and that there are no broken or damaged parts.

Cleaning

Your dresser can be cleaned by wiping with a damp cloth and drying with a soft clean cloth. Do not use abrasives, bleach, alcohol or ammonia based household polishes.

MAGICBABY LTD
Unit 7 Brookfields Way,
S63 5DL Manvers Rotherham,
United Kingdom

